



VHF S	UHF S	TXC	RMC	STATUS
H	L	H	L	VHF-TX
L	H	L	H	VHF-RX
L	H	L	H	UHF-RX
L	H	L	H	UHF-RX
X	X	L	L	-

VOUT	IN	CONT	NC
3V3	3V3	NC	NC

CC	IND	TEST	GND
5	4	3	2
1	2	1	1

VCC	AO	A1	A2	SDA	VSS
8	7	6	5	4	3

EXT	PTT
4	3

KEY POWER	KEY SW-4
4	3

EXT	PTT
4	3

KEY POWER	KEY SW-4
4	3

EXT	PTT
4	3

KEY POWER	KEY SW-4
4	3

EXT	PTT
4	3

KEY POWER	KEY SW-4
4	3